

TECHNICAL BULLETIN

TB-21-001

PROPER SCREWS FOR HOCHIKI SENSOR BASES

It has come to our attention that some dealers are using counter sunk screws to mount Hochiki sensor bases to back boxes. Counter sunk screws exert too much pressure on a small surface area of the base and can crack the plastic base. Hochiki bases are packaged with the appropriate pan head screws. If a different size screw is needed for your installation, then purchase pan head screws only.


Guidelines:

Use only hand tools to install screws and bases.

Do not use electric screw drivers to tighten screws. This practice can over-torque the screw and crack the base.

Damage to bases due to improper or poor installation practices will void the warranty of the base.

These guidelines apply to all Hochiki conventional and addressable detector/sensor bases.



If you have any questions regarding this matter, please contact Hochiki Technical Support.

Technical Support
1-800-845-6692
Technicalsupport@hochiki.com